




Welcome to your NOOK Tablet® 10.1"


Quick Start Guide

BNTV650

1 What's in the box



10.1" NOOK Tablet




Charger

Micro USB Cable

Quick Start Guide

2 Buttons and ports




***Quick Connector**
Used for easy docking to NOOK accessories.

3 Charge your NOOK

You must charge your NOOK before using it for the first time.

Connect your NOOK to a power outlet using the included charger and Micro USB cable as shown below.




The lightning indicator will appear in the battery icon when charging.



Power Button

Press and hold the power button until the startup screen appears.



Lock (standby)


Briefly press the power button (putting your NOOK in standby will help to conserve the battery).

Unlock

Briefly press the power button and slide the "Lock icon" upwards to unlock your NOOK.

4 Setting up your NOOK

Follow the initial setup wizard prompts to connect to Wi-Fi®, set the date and time, security and other options.



5 Register your NOOK

You must register your NOOK to your NOOK (or BN.com) account. This gives you access to any books in your NOOK Library and allows you to shop for new books, magazines, and newspapers on your NOOK.

If you already have a NOOK (or BN.com) account:

1. Tap *Sign In*.
2. Enter the email address and password for your account.

If you do not yet have a NOOK (or BN.com) account:

1. Tap *Create Account*.
2. Follow the prompts to fill in the form with your name, email, password, and other information.
3. Lastly, add a credit card for future purchases or *Skip*.



That's it. You've registered your NOOK. You're now ready to shop at the Bookstore and read your favorite books, magazines, newspapers, and more.

6 Home screen

On your Home screen, you can quickly access your current reads and navigate to the various features on your NOOK, like your Library and Bookstore.

Swipe up on the Home screen to open the App Drawer and access all your downloaded apps.




Tips: Press and hold an icon or widget to adjust its placement.

7 Notifications & Quick Settings

Swipe down from the top edge of the screen to expand and see your app notifications, and swipe a second time to reveal the Quick Settings panel to adjust some common settings.

To access more settings options, select the  icon.



8 Shop at the NOOK Bookstore

Once your NOOK account is set up with a valid credit card, you can make purchases with the tap of your finger. Your NOOK adds the item to your Library automatically.



Building Your Wishlist
Save items for later by adding them to your Wishlist. Tap the heart icon along the top to visit your Wishlist. You can also view it on bn.com.


Search the NOOK Bookstore
Tap the search button to display an on-screen keyboard to search by a title, author name, or topic.

Explore Bookstore
Visit FOR YOU for recommendations from Barnes & Noble booksellers or go to CATEGORIES to browse by genre.

Browse Popular Lists
Choose a popular list to get easy access to recommended reads.

9 Start reading

Reading a Book
You'll find your books, magazines, and newspapers in your Library. Tap on the cover to download and start reading.




Tips: Press and hold a book cover for additional actions.

Turn Pages
To turn the page of a book forward or back:
• Tap the right or left edge of the screen.
• Swipe from right to left or left to right as shown below.




Change Text Size & More
When in a book, tap the center of the screen to bring up the Reading Tools. To adjust the text, tap the text icon in the top corner and select your text size, font style, and other options.


You can also browse the table of contents and view your notes and bookmarks, search for words or phrases, and go to a specific page number.



10 Google Play



Google Play is a digital content experience from Google™ where you can find and enjoy your favorite music, movies, TV shows, and Android™ apps and games. It's your entertainment hub: you can access it from the web or from your Android device, and all your content is instantly available across your devices.




11 Expanding the storage

Inserting a MicroSD™ card
Your NOOK supports MicroSD cards up to 256GB (not included). Refer to the user guide for compatible MicroSD card models.

To install a MicroSD card, carefully insert the card as shown below into the card slot until it clicks and locks into place.

To remove the MicroSD card, gently press it inward to eject.

For more details, please refer to the User Guide.



Your NOOK offers several options to optimize the available storage on your NOOK Tablet. Please refer to the user guide for more details.

12 Learn more

User Guide
In addition to this Quick Start Guide, please read the User Guide for complete information about all the features of your NOOK. You'll find a copy of the User Guide in your NOOK Library.

Additional Support
Please visit NOOK.com/support for additional information, including:
• A PDF version of the NOOK® User Guide that you can download to your computer
• Frequently Asked Questions
• Live Chat with a NOOK Expert

You can also tweet Customer Service at @NOOK_Care.

To protect your NOOK's screen from accidental damage, we recommend using a NOOK cover. Your limited warranty does not cover damage to your NOOK's screen resulting from accidental drops or regular wear & tear.

Nook Digital, LLC. 1166 Avenue of the Americas, 18th Floor, New York, NY 10036
© 2018 Nook Digital, LLC. All rights reserved. NOOK, NOOK Tablet, NOOK Store, B&N Readouts and the NOOK logos are trademarks or registered trademarks of Nook Digital, LLC or its affiliates. Patent Pending. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All trademarks or registered trademarks that are not the property of Nook Digital, LLC or its affiliates are the property of their respective owners. Screenshots and product images are simulated; they may differ from the actual product and are subject to change. Use of NOOK is subject to the Nook Device Terms of Service and Privacy Policy located in the Settings area of your device and at www.NOOK.com/legal. Contains Reader® Mobile technology by Adobe Systems Incorporated.

Google, Android, Google Play and other marks are trademarks of Google LLC.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOOK Support
For additional assistance and information, please refer to the comprehensive User Guide found in the NOOK Library on your device as well as on NOOK.com. You can also contact Customer Service at 1-800-THE-BOOK to speak with a Customer Service Representative.